Revio-868 P No. 28 410.0006








Contents


Device Explanation	3
Safety Notes	4
Exclusion of Liability	4
Scope of Delivery / General	4
Intended Use	4
Exclusion of Liability	4
Notes on Radio Operation	5
Assembly / Connection	6
Assembly and Connection	6
Connection of Drive	
Connection of ProLine Controller	7
Connection of Drive and External Control	7
Best Use of the Radio Signal	8
Declarations	8
Out ▲ ▼ Connection Terminal	
Roller Shutter Jumper between JA and L	9
Jumper between PU and L	9
Group Control Jumper between GR and L	9
P Button	9
Teaching in Transmitter / Channel	12
Commissioning	12
Teaching in further Transmitters	12
Programming Positions	12
Moving to Positions	12
Deleting Positions / Transmitters	12
Technical Data	
Disposal	13
Notes on Troubleshooting	13
Manufacturer's Statement	14

Device explanation

Device explanation



Safety instructions / exclusion of liability



Exclusion of liability:

It is essential to observe these operating instructions for use if the Revio-868 P / Revio-915 P is to be used safely and if the various product characteristics and performance features are to be achieved.

elero GmbH assumes no liability for personal injuries, property damages and financial losses that arise from non-observance of the operating instructions.

Liability for material defects is excluded in such cases.

Safety instructions

CAUTION!

Observe the following safety instructions. Failure to observe them can lead to bodily injuries!

General

- · Never install or use damaged products.
- · Only use unmodified original elero parts
- If the device is opened without permission or used in an improper manner, or if it is incorrectly installed or operated, there is a risk of damage to persons and property.
- The device contains small parts which can be swallowed.

Installation

- All installation work must be carried out by a electrician.
- · This electrician must be suitably qualified.
- Observe any country-specific conditions when installing the device.
- The device may only be used by persons who have read and understood the operating instructions.

Operation

- Use only in dry rooms.
- If one or more transmitters are used for controlling the system, its operating range must stay visible during operation.
- · Keep children away from the controls.

Scope of supply / general information / Intended use

Scope of supply

Revio-868 P / Revio-915 P Operating instructions

General information

The Revio-868 P / Revio-915 P is an flush mounted radio receiver. It is suitable for control of 230 V roller shutter, blind and venetian blind motors.

In addition you can control all ProLine control units as well as control units from another manufacturer via the potential-free outputs.

Intended use

The radio receiver may only be used to control roller shutters, sun protection and roller shutter systems, that are fitted with elero drives.

Other use, or use beyond this is not considered to be use for intended purpose.

Exclusion of liability

elero GmbH shall not be liable for damage caused by:

- · Other use than described above
- · Changes to the device
- Improper use

Please see the technical data contained in these operating instructions.

Third-party devices should only be connected after consultation with specialised trade.

CAUTION!

Observe the following safety instructions on radio operation.

Only use radio systems if they are allowed and can be operated without interference.

- Please note that radio systems must **not** be operated in areas with an increased risk of interference (e.g. hospitals, airports, ...).
- Remote control is permitted only for devices and equipment for which a malfunction of the transmitter or receiver does not give rise to a hazard to persons, animals or objects or where this safety risk is covered by other safety equipment.

Installation/connection

Installation and connection

NOTE!	
Before installation in the required assembly position, check that the transmitter and receiver are function- ing properly.	
The flush-mounted socket has to be fixed so that the drill hole does not touch any electrical lines.	

Connection

You can find the structure of a controller on elero.com in the download area under "Installation instructions and circuit diagrams".



WARNING!

Danger of injury from electric shock.

- The connection must only be made by an authorized specialist!
- The device only offers protection against touch by the back of the hand, no protection against accidental contact.
- Do not kink, shorten or extend the aerial.
- Only operate the learning button **P** with insulated tools (4 KV voltage protection).
- If more than one drive is controlled using the Revio-868 P / Revio-915 P the drives must be decoupled with relay controls.
- Note the switching current of the device.


CONDITION!


Flush-mounted socket Ø 58 mm, 60 mm deep.

Connection


- 1. Place the Revio-868 P / Revio-915 P in the socket.
- 2. Connect the stripped cable ends without connector sleeves as follows:

Drive connection





Connection of drive and control unit from another manufacturer



Optimal use of the radio signal

Optimal use of the radio signal

- Do not kink the aerial.
- Do not shorten or extend the aerial.
- · If reception is poor, adjust the antenna. position
- · Install the antenna so that it is as exposed as possible.
- · Antenna is not to rest on metal.
- · Using a number of receivers may cause interference.

NOTE!

Radio systems, which operate on the same frequency, can lead to reception of interferences.

Please note, that the range of the radio signal is limited by the government and the built environment.

Out ▲ ▼ Connection terminals

The outputs are intended for subsequent controls, but a drive can be connected as well if wired accordingly.

The arrows on the device indicate the direction of travel.

Explanation

Venetian blind jumper between JA and L

If a wire jumper is used between L and coding terminal JA you can use the Revio-868 P / Revio-915 P to control a roller shutter system in stepping mode. If you press a travel key for longer than 3 seconds, however, the Revio-868 P / Revio-915 P goes into maintained mode.

Jumper between PU and L

The Revio-868 P / Revio-915 P can be used for precise setting of the lamellas with a roller shutter drive. This Revio-868-P / Revio-915 P is fitted with a pulse drive for this purpose. This means that the drive is triggered for the pulse period for each brief press of the button on the transmitter. This pulse time can be modified on the transmitter if a pulse period other than the standard pulse time is desired.

Group control jumper between GR and L

If a wire jumper is used between L and coding terminal GR you can use the Revio-868 P / Revio-915 P to control a group.

P button

A break in the power supply is simulated by pressing the **P** button (needed to program the transmitter).

Teaching in Transmitter/Channel

Initial operation

(Connection for a tubular or venetian blind motor or ProLine or third-party control)



CONDITION!

The Revio-868 P / Revio-915 P is installed. (\rightarrow see chapter on connection of RM/JA) The end positions must be set.

- When the power supply is restored or by pressing the P-button (at least 5 seconds) on the Revio-868 P / Revio-915 P, the device is ready to programme for 5 minutes.
- 2. Program the transmitter (\rightarrow see transmitter instructions).

Programming further transmitters

 \rightarrow see transmitter instructions

Programme positions

 \rightarrow see transmitter instructions

Approach positions

 \rightarrow see transmitter instructions

Deleting positions/deleting transmitters

 \rightarrow see transmitter instructions

Technical Data/Disposal/ Notes on Troubleshooting

Technical Data

Rated voltage	230 V - 240 V / 50 - 60 Hz
Switching current	3 A
Protection type	IP20
Permitted ambient temperature	0 to +55 °C
Radio frequency	868 MHz/50 Hz
Mounting	Flush-mounted Ø 58 mm wall installation Surface-mounted in correspond ing housing
Dimensions	L 50 x W 48 x H 27 mm
Maximum number of transmitters	16

Disposal

Dispose of the transmitter according to the current electrical waste disposal regulations of the country concerned (e.g. suitable collection points).

Notes on Troubleshooting

Fault	Cause	Remedy
Drive does not run	False connection	Check connection.
Drive operates in the wrong direction	Directions are incorrect- ly programmed.	Delete transmitter and program correctly.
No radio reception	 Transmitter is not programmed No mains voltage 	 Programming the transmitter Switch on power supply.
Bad radio reception	Aerial or receiver in unfavourable position.	Change position of receiver or aerial.

EC Declaration of conformity

elero GmbH hereby declares that the radio system type Revio-868 P is in compliance with Directive 2014/53/EU. The complete text of the EU Declaration of Conformity is available at the following Internet address:

www.elero.com/downloads-service/

Address

elero GmbH Antriebstechnik Maybachstr. 30 73278 Schlierbach Deutschland / Germany Tel: +49 7021 9539-0 Fax: +49 7021 9539-212 info@elero.de www.elero.com Please visit our website if you require a contact outside Germany.

Technical changes reserved